



Accessible Voting System Set-up Operation

Make note: the one4all system uses the “Official” printed ballot that everyone uses whether Accuvote or Hand Count.

Toll Free Help Line – 1-800-540-5954
or 603-271-8241

November 2020

NEW HAMPSHIRE

Accessible Voting System

Table of Contents

• INTRODUCTION	Pages 2 - 3
• EQUIPMENT	Pages 3 - 8
• SET UP	Pages 9 - 15
• OPERATION	Pages 15 – 22
• SHUTTING DOWN	Page 23
• RETURNING THE TABLET	Page 24

Introduction

The Help America Vote Act of 2002 (HAVA) requires at least one voting system equipped for individuals with disabilities at each polling place, including nonvisual accessibility for the blind and visually impaired. The State of New Hampshire has decided to deploy a tablet based voting system to satisfy this requirement.

This system is called the **one4all** Accessible Voting System. **one4all** is designed to accommodate persons who cannot mark a “Official” paper ballot without assistance.

one4all provides a voter with multiple options to access and mark a ballot in private. The system marks an “Official” printed ballot, the same ballot that everyone uses whether they are Accuvote or Hand Count. **No telephone or internet connections are required or supported by this system.**

PLEASE TEST THE SYSTEM AS SOON AS POSSIBLE.

**CALL THE HELP DESK IMMEDIATELY IF YOU HAVE
ANY ISSUES. 603-271-8241 OR 800-540-5954**

Note to Moderators

The Moderator or Clerk shall test the one4all system prior to Election Day and on the morning of the election to ensure the system is up and running.

Moderators should take steps to ensure that more than a single voter uses the system. We recommend that at least five (5) voters use the system so that the **one4all** ballots cannot be linked to a voter or voters using the system. We trust in the judgment and discretion of our Moderators to address this issue in their own way.

EQUIPMENT

The system hardware is composed primarily of a Dell tablet, a Dell folio tablet cover, a Dell docking station, Jabra Headphones, an EZ Eyes keyboard and a Brother Laser printer.

All of the equipment required to operate the *one4all* Accessible Voting System from your polling place is contained in the green and blue plastic storage containers with the exception of the **TABLET**. The printer is stored in the blue container.

The **TABLET will always be shipped separately for each *State* Election.**

Make sure you have all the equipment necessary to operate the one4all accessible voting system. If you have equipment that is damaged or missing, please contact the Help Desk immediately. Please check your equipment ahead of time, do not wait until the day of the election so we may get the needed supply to you.

This equipment includes:

- *Tablet w/ Folio Cover – Dell 11 Pro 7000 Series (7140) Tablet (64GB)*
- *Dell Docking Station with Power Cord/AC Adapter*
- *Brother HL-6250DW Laser Printer*
- *Printer Cable – 3 foot USB A/B*
- *Keyboard – EZ Eyes AKB-8861 high contrast*
- *Headphones – Jabra UC Voice 150 MS Duo*
- *50 foot power extension cord*
- *a surge protector power strip*
- *a desk lamp for added illumination*
- *a Mini Vote Access Kit –
clip board, sheet magnifier, signature template, deaf/HOH
communication card, poll worker disability assist buttons*

*****IMPORTANT*****

Please follow these instructions step by step as the system will only work in this sequence.

STEP ONE

UNPACK ALL EQUIPMENT

Tablet


Dell Venue 11 Pro 7000 Series (7140) Tablet 64GB

Volume Control



Start Button

Port for attachment
to Docking Station



Docking Station

Dell Venue 11 Pro (7140) Tablet


Front View

Mount Connection for Tablet
(Power Supply for Tablet)

USB Port
for Headset



Rear View



USB Headphones

Jabra UC Voice 150 MS

Headset Adjustment



Volume Control



USB Connector



50 Foot Power Extension Cord

Keyboard

EZ Eyes Model No. HPO-J1305

USB Connector



Surge Protector Power Strip
(Must be in “Off” position)



Black Desk Lamp



Mini Vote Access Kit

Printer

Brother HL-L6250DW Laser Printer

USB Connector to
Docking Station



Power Cord



 Paper Tray

SET UP

STEP TWO

Connect All USB Ports to the Docking Station



- a. The **KEYBOARD** and the **PRINTER CABLE** connect to the **rear** of the **DOCKING STATION** with **USB connectors**.

(See page 6 for picture of the rear of the docking station.)

- b. The **HEADPHONES** connect to the **front** of the docking station in the USB Port. (See page 5 for picture of the front of the docking station.)



HEADPHONES

- c. Plug the **light-colored connector cable**, into the **rear** of the **PRINTER** on the side opposite the power cord.



- d. Connect the two-piece **AC ADAPTER** together and plug it into the **DOCKING STATION**.



- e. Plug the power end of AC ADAPTER into the **surge protector power strip**.

- f. The **PRINTER** has a **power cord** to be plugged into the rear of the printer and the other end directly into the **surge protector power strip**, **while in the “OFF” position.**



- g. Connect the **surge protector power strip** to a wall outlet and turn the power button to the “**ON**” position. (If necessary, use the extension cord to connect to the wall outlet.)

STEP Three

Turn on the Printer First

The **Power** button is located on the top left side of the **PRINTER**. Press and hold for 3 – 5 seconds to power up.

START



STEP Four

Remove the “Folio Cover” from the **TABLET** which is attached to the tablet with magnets. Hold the folio cover in one hand and the tablet in the other hand and gently tug the folio cover away from the tablet to completely remove it. Do NOT remove the back cover. Store the folio cover in its cardboard box until election night.

Connect the **TABLET** by gently setting it onto the pins on the **DOCKING STATION** and then lay the tablet back on the **DOCKING STATION**.



There is a **connection port** located at the bottom center of the **TABLET**.



The **TABLET** connects (*gently*) to the **DOCKING STATION**




Tilt the **TABLET** back so it is resting on the **on the back of the DOCKING STATION** at a **slight angle**.


STEP Five

Turn on the Tablet

The **Power** button is located on the upper right side of the **TABLET**. Press and hold the power button in until the tablet vibrates.



The Tablet screen will appear as below.



Confirmation Screen:

On confirmation screen confirm the ballot selection and touch “Continue”

You have chosen the ballot for:


New Hampshire General Tuesday November 3, 2020


Anytown

Back Continue

Ask the voter which experience they would like to use – “Touch” or “Keyboard”

Please select an experience


Touch


Keyboard

- Select the **“Touch”** icon for the voter who wishes to use the *tablet screen*
 - The instructions on the screen OR on the headset, will instruct the voter how to navigate.
 - The headset will always stay on, no matter if the user selects the “Touch” or “Keyboard” icon.



Instructions



Touch any item on the screen to hear it read to you (audio only)





Touch an item to make a selection on a contest

Touch again to un-select an option

If available, touch Write-In to enter a name not on the ballot.


 


- The “T” icon allows the voter to make the text larger. 
 - The “volume” icon allows the voter to adjust the sound. Press the “**Up**” arrow to **increase** the volume. To **decrease** the volume, continue to press the “**Up**” arrow to cycle through the range from 0% to 100%. 
 - The “contrast” icon allows the voter to change the contrast on the screen. 
 - The “arrows” icon allows the voter to change the rate of speech range to be slower or faster. Press the “**Down**” arrow to increase the rate of vocal speed, continue to press the “**Down**” arrow to cycle through the rate of speed range from 0% to 100%. 
- Select the “**Keyboard**” icon for the voter who wishes to use the keyboard

- The “Keyboard” use is limited to the keypad on the right of the keyboard, using the left and right “arrows” and “Enter” button for navigation.



- The verbal instructions through the headset will instruct the voter in how to navigate.
 - The headset will always stay on, no matter if the user selects the “Touch” or “Keyboard” icon.

- The “Keyboard” instructions have all of the icons from the “Touch” screen listed above.
- It has an additional icon of the “Eyeball” which allows the voter to darken or restore the screen.
 
- The darkened screen appears as seen below.



OPERATION

The election official assigned to assist voters at this station will:


1. After pressing on the “Touch” or “Keyboard” icon, the tablet will advance to the first voting screen.
2. Verify that the first candidate listed on the screen is the same candidate that is listed first on the “Official” printed ballot.

3. Open the paper tray in the front of the PRINTER. (Choose the instruction below for the ballot that is applicable to your city/town)


8.5 X 14 inch Ballot:

The paper tray must be extended to receive this size ballot. To extend the paper tray:


- a. Remove the paper tray from the printer.
- b. In the rear of the tray, press (pinch) and hold the green lever (shown)



- c. Gently slide the back of the tray away from you until it is fully open.




- d. Next, pinch and hold the green tab located on the gray paper length extender tab that is defaulted to “LTR” (letter). Slide the gray tab all the way to the rear of the tray to “A4/LGL” (legal).



- e. Insert the paper tray back into the printer.


- f. Insert the “**Official**” ballot, Face Up and Header First into the tray.



******Note: Remember to slide the tray back into the default, “LTR” position, before storing it in the blue bin to avoid any breakage.***

8.5 X 11 inch Ballot:


Insert the “**Official**” ballot, Face Up and Header First into the tray.



**Call the HAVA office at 603-271-8241
IMMEDIATELY, if the election official is
having ANY issues with the tablet.**

TABLET

1. The election official may “End Session” at any time to start over.



Official Ballot - New Hampshire General Tuesday November 3, 2020 (Andover) End Session X


Instructions
Press the left and right arrow keys to move through the screen.
Press the Enter key to make a selection.
Press the Enter key again to deselect.
Select Write-In to enter a name not on the ballot.
Press the up arrow to change volume
Press the down arrow to change rate

President and Vice-President of the United States
Vote for not more than 1

- ☐ **Joseph R. Biden and Kamala D. Harris**
Democratic
- ☐ **Donald J. Trump and Michael R. Pence**
Republican
- ☐ **Jo Jorgensen and Jeremy Cohen**
Libertarian
- ☐ **Write-in**

Review My Ballot Contest 1 of 14 Next Page

2. You will receive a pop up stating:
“Are you sure you want to end your session?”
 - Touch “Cancel” or “Yes” on the screen.



End Session


Are you sure you want to end your session?

Cancel Yes

NAVIGATION OF THE KEYBOARD

NOTE: Ask the Voter if they need assistance with the KEYBOARD, if so, guide the voter to place their fingers on the “right and left arrow” keys and the “Enter” key.

- Use the “Enter” key when prompted by the audio to “Continue”.
- Use the “Right & Left Arrows” to navigate through the candidates and press the “Enter” key to go the ‘Next Page.’
- Use the “Up” arrow to change volume.
- Use the “Down” arrow to change rate of speed.




- Use the keyboard letters to type in a write-in candidate name. Press the left or right arrow key to continue.



3. Election Official leaves the booth after giving the voter the following instructions:

- a. The election official advises the voter they are on the first office on the ballot screen.
- b. The election official gives the voter a “Ballot Privacy Folder” to put their completed ballot in to bring to the Moderator (or appointed official) overseeing the ballot box or ballot counting device.



- c. They will navigate through the instructions using the right and left arrow keys.
- d. To select a candidate, the user will press on the “Enter” key.
- e. Once a candidate has been selected, the voter continues to press on the right arrow key until they hear or see “Next Page.”
- f. The user will press on the “Enter” key to continue to “Review My Ballot.”

Reviewing the Ballot

1. The voter may review the ballot by office and change the candidate selection by touching the “Change” button on the screen.

- a. If the user has no changes, they will press the right arrow key until they hear “Accept and Print.”

Official Ballot : New Hampshire General Tuesday November 3, 2020 (Andover) End Session X

Review Your Selections


Your ballot selections are listed below.
 You may change any selection by clicking the Change link next to your selections.
 After you have reviewed your selections press the Accept and Print button.
 Please note that once you press Accept and Print your marked ballot will be printed and you cannot get back to your voting session.

President and Vice-President of the United States Vote for not more than 1	No Selections	Change
Governor Vote for not more than 1	No Selections	Change
United States Senator Vote for not more than 1	No Selections	Change
Representative in Congress Vote for not more than 1	No Selections	Change
Executive Councilor Vote for not more than 1	No Selections	Change
State Senator Vote for not more than 1	No Selections	Change

[Accept and Print](#)

- b. The user may submit the ballot at any time by touching the “Accept and Print” button or pressing the “Enter” key.


- c. When the ballot is submitted, the system marks the “Official” ballot in the printer.




d. The screen will appear as above.

2. If the ballot does not print, the user can touch the button on the screen or press the “Enter” key. This will lock the screen.

3. The poll worker will then enter the 5-digit code on the screen for their town or city ward and touch “Done.”



4. The poll worker will touch “Reprint Ballot.”
5. After the ballot has printed, the system will return to the one4all screen.



No voting information is stored on the tablet.

The TABLET never sleeps. The screen should be on all day long at the polling place.

Shutting off the Tablet & Printer at the end of Election Day

FIRST - Shut the Tablet down, by pressing the “SHUTDOWN” button.

- It will take 2 – 3 seconds for the printer removal prompt to appear.
- Press “OK” on the pop-up window and the tablet will shut down.



SECOND – Shut down the Printer

- Hold the power button for 3 – 5 seconds.

*****Note: For town/city with 8 1/2 X 14 in ballots, remember to slide the printer tray back in to the default LTR position before storing it in the blue bin to avoid any breakage*****

THIRD – Turn the surge protector to the “Off” position. Unplug all plugs remaining in the surge protector. Unplug the surge protector from the wall.

FOURTH – When the tablet has shut down, find the tablet’s brown cardboard box. (It should be stored in the green AVS bin.)

- Place the “Folio Cover” on the TABLET
- It has two magnetic prongs that fit on the “Windows” symbol side of the tablet.
- Place the tablet in its brown cardboard box and secure the box with the two elastics.



**THE TABLET MUST BE RETURNED ELECTION NIGHT
WITH THE RETURN OF VOTES PAPERWORK**

*****IMPORTANT*****

Give the tablet to the City/Town Clerk to return it with the “Return of Votes” envelope to the Secretary of State’s office Election Night.

